

Instruction Manual

SUNJE
Electrostatic

X

SXN-05/10BT Communication

Tai

1 RS-485 Communication

1. Pin
- 24號 Pin : RS-485(+)

- 25號 Pin : RS-485(-)
2. Communication Spec.
- Baud : 9600

- Parity Bit : None

- Data Bit : 8

- Stop Bit : 1

2 Communication Protocol

kV

Product Type

Ionizer Model

123456789

5

E

A B C D E F G H I

10

a b c d e f g h i

※ 根據連接的 Tube數量 / 管電壓數據來通信識別不壹樣

1. Data Request

通信設備 → SXC-10BT

Byte	0	1	2	3	4	5	6	7	8	9	10	11	12	13
Code	\$	P	M	,	R	E	Q	,	A	*	Checksum	CR	LF	

Byte	Information	Byte	Comment	Remarks
0	Start Code	1		
1	Product Type	1	Photo Type Ionizer	E : SXC-10BT
2	Ionizer Model	1	5kV : A ~ I, 10kV : a ~ i	
1, 2	Broadcasting	2	ZB	無論產品群及產品名皆反應
4, 5, 6	Command	3	REQ : Request, RUN : Run, STP : Stop	Bar的 Tube數量來區分 (最多 9個連接)
8	Address	1	Photo : 1 ~ 16	1,2,3,4,5,6,7,8,9,A,B,C,D,E,F,G
9	End Code	1		
10, 11	Check Sum	2	Check Sum	
12, 13	Carriage Return, Line Feed	2		

1. Data Receive					通信設備 ← SXC-10BT										
Byte	0	1	2	3	4	5	6	7	8	9	10	11	12	13	
ASCII	\$	P	M	,	A	,	T/C	,	T/O	,	T/A	,	Tube		
Byte	14	15	16	17	18	19	20	21	22	23	24	25	26	27	
ASCII	Run Time(1)				,	T/C	,	T/O	,	T/A	,	Tube Run Time(2)			
Byte	28	29	30	31	32	33	34	35	36	37	38	39	40	41	
ASCII		,	T/C	,	T/O	,	T/A	,	Tube Run Time(3)				,		
Byte	42	43	44	45	46	47	48	49	50	51	52	53	54	55	
ASCII	T/C	,	T/O	,	T/A	,	Tube Run Time(4)				,	T/C	,		
Byte	56	57	58	59	60	61	62	63	64	65	66	67	68	69	
ASCII	T/O	,	T/A	,	Tube Run Time(5)				,	T/C	,	T/O	,		
Byte	70	71	72	73	74	75	76	77	78	79	80	81	82	83	
ASCII	T/A	,	Tube Run Time(6)				,	T/C	,	T/O	,	T/A	,		
Byte	84	85	86	87	88	89	90	91	92	93	94	95	96	97	
ASCII	Tube Run Time(7)					,	I/S	,	R/S	,	P/S	,	A/S	,	
Byte	98	99	100	101	102	103									
ASCII	R/S	*	Checksum	CR	LF										

※ Tube 7個 Model標準

Byte	Information	Byte	Comment	Remarks
0	Start Code	1		
1	Product Type	1	Photo Type Ionizer	E : SXC-10BT
2	Ionizer Model	1	5kV : A ~ I, 10kV : a ~ i	Bar的 Tube數量來區分 (最多 9個連接)
4	Address	1	Photo : 1 ~ 16	1,2,3,4,5,6,7,8,9,A,B,C,D,E,F,G
6	Tube1 Connect	1	1 : Normal	1 : Tube Con(常時)
8	Tube1 Over Time	1	0 : Normal, 1 : Abnormal	Over Time時 Abnormal
10	Tube1 Alarm	1	0 : Normal, 1 : Tube Fail, 3 : Comm out	0之外 Abnormal
12 ~ 16	Tube1 Run Time	5	00000 ~ 99999 Hour	
18	Tube2 Connect	1	1 : Normal	1 : Tube Con(常時)
20	Tube2 Over Time	1	0 : Normal, 1 : Abnormal	Over Time時 Abnormal
22	Tube2 Alarm	1	0 : Normal, 1 : Tube Fail, 3 : Comm out	0之外 Abnormal
24 ~ 28	Tube2 Run Time	5	00000 ~ 99999 Hour	
30	Tube3 Connect	1	1 : Normal	1 : Tube Con(常時)
32	Tube3 Over Time	1	0 : Normal, 1 : Abnormal	Over Time時 Abnormal
34	Tube3 Alarm	1	0 : Normal, 1 : Tube Fail, 3 : Comm out	0之外 Abnormal
36 ~ 40	Tube3 Run Time	5	00000 ~ 99999 Hour	

Byte	Information	Byte	Comment	Remarks
42	Tube4 Connect	1	1 : Normal	1 : Tube Con(常時)
44	Tube4 Over Time	1	0 : Normal, 1 : Abnormal	Over Time時 Abnormal
46	Tube4 Alarm	1	0 : Normal, 1 : Tube Fail, 3 : Comm out	0之外 Abnormal
48 ~ 52	Tube4 Run Time	5	00000 ~ 99999 Hour	
54	Tube5 Connect	1	1 : Normal	1 : Tube Con(常時)
56	Tube5 Over Time	1	0 : Normal, 1 : Abnormal	Over Time時 Abnormal
58	Tube5 Alarm	1	0 : Normal, 1 : Tube Fail, 3 : Comm out	0之外 Abnormal
60 ~ 64	Tube5 Run Time	5	00000 ~ 99999 Hour	
66	Tube6 Connect	1	1 : Normal	1 : Tube Con(常時)
68	Tube6 Over Time	1	0 : Normal, 1 : Abnormal	Over Time時 Abnormal
70	Tube6 Alarm	1	0 : Normal, 1 : Tube Fail, 3 : Comm out	0之外 Abnormal
72 ~ 76	Tube6 Run Time	5	00000 ~ 99999 Hour	
78	Tube7 Connect	1	1 : Normal	1 : Tube Con(常時)
80	Tube7 Over Time	1	0 : Normal, 1 : Abnormal	Over Time時 Abnormal
82	Tube7 Alarm	1	0 : Normal, 1 : Tube Fail, 3 : Comm out	0之外 Abnormal
84 ~ 88	Tube7 Run Time	5	00000 ~ 99999 Hour	
※ 根據連接的 Tube數量通信 Data Byte會有變化。				
90	Controller Interlock State	1	0: Interlock Off, 1: Interlock On	
92	Controller Remote State	1	0: Remote Off, 1: Remote On	
94	Controller Power State	1	0: Power Off, 1: Power On	
96	Controller Alarm State	1	0 : Normal, 1 : Tube Fail, 3 : Comm out	Tube Alarm 1個以上發生時 Abnormal
98	Controller Run/Stop State	1	1 : Run, 0 : Stop	
99	End Code	1		
100, 101	Check Sum	2	CheckSum	
102, 103	Carriage Return, Line Feed	2		

※ Tube 7個 Model標準

2. Control [Run]				通信設備 → SXC-10BT											
Byte	0	1	2	3	4	5	6	7	8	9	10	11	12	13	
Code	\$	P	M	,	R	U	N	,	A	*	Checksum	CR	LF		

2. No Receive	通信設備 ← SXC-10BT
---------------	-----------------

3. Control [Stop]				通信設備 → SXC-10BT											
Byte	0	1	2	3	4	5	6	7	8	9	10	11	12	13	
Code	\$	P	M	,	S	T	P	,	A	*	Checksum	CR	LF		

3. No Receive	通信設備 ← SXC-10BT
---------------	-----------------

Checksum Calculation

\$ ~ * Calculation

```
#include<stdio.h>

void main()
{
    char packet[] = "EG,REQ,1", cksum = 0;
    int i, size = 0;

    while(packet[size] !='W0') size++;

    for(i = 0 ; i < size ; i++)
    {
        if(i == 0)
            cksum = packet[i];
        else
            cksum^= packet[i];
    }
    printf("Request : $EG,REQ,1*% .2X",cksum); //Checksum character send by ASCII.
}
```

※ Checksum檢查是將從 \$ 表示到 * 的所有數據以 Exclusive-Or聯算的。

SUNJE Electrostatics

www.sunstat.com

Head Office & Factory (Busan)

8, Cheonggwang-gil, Ilgwang-Myeon, Gijang-Gun, Busan, Korea

T) +82-51-720-7500 F) +82-51-720-7501

Central Sales Office (Hwaseong)

3F, Ilshin B/D, 4, Namnyeoul 2-gil, Hwaseong-si, Gyeonggi-do, Korea

T) +82-31-203-9034 F) +82-31-202-9034

Southern Sales Office (Chilgok)

35-2, Seojungni 3-gil, Seokjeok-eup, Chilgok-gun, Gyeongsangbuk-do, Korea

T) +82-54-476-9033 F) +82-54-476-9034

Customer Center

+82-70-7714-9033

Sales Contact

+82-31-203-9034

Sunje America Co., Ltd.

1855 41st Ave. #D4 Capitola, CA 95010, USA

T) +1-510-332-8613 F) +1-888-764-1429

Sunje Japan Co., Ltd.

3-11-16-321 Higashimikuni, Yodogawa-ku, Osaka, Japan

T) +81-6-4866-5202 F) +81-6-6399-9290

Sunje (SHANGHAI) Trading Co.,Ltd.

Room 312, Jiurun Business Building 3rd Floor,No. 298, Yindu Road, Xuhui District, Shanghai, China 200000

T) +86-21-5433-9761 F) +86-21-5433-9762

Sunje Technology Co., Ltd.

2F, No.6, Lane.102, Sinhe Rd, Sinfong Township, Hsinchu County, Taiwan 30472

T) +886-3-568-7891 F) +886-3-568-7950

Copyright 2016. SUNJE Hi-Tek Co., Ltd. All Rights Reserved.

 KCC

 INNOBIZ

 KAB

 KOSPI