Instruction Manual SUNJE

SBP-RD



It is recommended that only persons who have sufficient knowledge and experience such as system designers and responsible persons deal with this product after carefully reading the product manual

1 The matters of safety

MARNING

- * If the equipment is used in a manner not specified by the manufacturer the protection provided by the equipment may be impaired.
- * Do not let the water touch the product
- It may cause electric shock or fire due to malfunction. When you check or maintain the product, make it sure you turn off the power
- It may cause electric shock or fire due to malfunction.
- The item should be fixed to the target tightly. Electric discharging or breakage might happen
- * Do not use the product at the place where dangerous material such as inflammable or ignitable material exists. This product is not the product of anti-explosive type.
- This device is made only for industrial uses. You need to ground the device beforehand. Otherwise, there are in case of malfunction, electric shock, or fire damage.


CAUTION


- Do not disconnect the controller cable with power applied. There is a possibility of electric shock or malfunction
- Connect wires referring to the product manual. Wrong connection can cause failures.
- * For your proper cable connection, take a look at the manual [Installation & Connection] for references. Any disordered connection is detected, the malfunction might arise.
- All cables should be connected all the time. Please careful of cable disconnections. If power or communication cables got damaged, replace them immediately. Malfunction and fire danger may happen
- Do not install the device where the vibration can be detected. Any minor impact or vibration on the device, the malfuction or danger of accident might happen.
- Do not use the item off the range of usage(Electrostatic elimination). Malfunction or danger of accident may occur


2 Check the package contents

▶ Product compositions

The package includes the following products composition.









3 Nomenclatures of parts

▶ DC Power Supply (SBP-RD)

Front


When there is not a power source for DC 24V on an installation point or equipment, it can supply DC 24V to SIB series and be connected up to Max. 4sets.






4 Installation and connection


▶ Ion bar connection



▶ Power Cable & Ground connection



5 Dimensions



6 Specification

Parameter	Description / Value
Input Power	AC 100~240V, 50/60Hz
Power Consumption	Max. 80W
Weight	1.85kg
Main Body Material	EGI
Operation Circumstance	0℃~+50℃(32°F~122°F), 35%~85% RH
Output Voltage	DC 24V Max. 3A
Output Port	4 Ports
Warranty	1 Year

* The appearance and specification of the product may be changed without prior notice for the improvement of the product

SUNJE Hi-Tek Co., Ltd.

www.sunstat.com

Head Office & Factory (Busan)

8 Cheonggwang-gil, Ilgwang-eup, Gijang-Gun, Busan, Korea T) +82-51-720-7500 F) +82-51-720-7501

Sales Headquarter (Osan)

3rd floor, 129-20, Gyeonggi-daero 632 beon-gil, Osan-si, Gyeonggi-do, Korea T) +82-31-203-9034 F) +82-31-202-9034

Sunje (SHANGHAI) Trading Co.,Ltd. 205B, Building A, No.1018 Mingzhu Road,

Oingpu District, Shangha, China T) +86-21-5433-9761 F) +86-21-5433-9762

Sunje Technology Co., Ltd.

2F, No.6, Lane.102, Sinhe Rd, Sinfong Township, Hsinchu County, Taiwan 30472 T) +886-3-568-7891 F) +886-3-568-7950

Customer Center +82-70-7714-9033

Sales Contact +82-31-203-9034