

It is recommended that only persons who have sufficient knowledge and experience such as system designers and responsible persons deal with this product after carefully reading the product manual. We are not responsible for accidents caused by not following the instructions and precautions in the product manual.

1 The matters of safety

⚠ WARNING

- * Do not fabricate or do maintenance by yourself. Malfunction, Electric shock, and fire danger are considered. Contact us directly if you need the item to be repaired.
- * Do not let the water touch the product. It may cause electric shock or fire due to malfunction.
- * When you check or maintain the product, make it sure you turn off the power. It may cause electric shock or fire due to malfunction.
- * The item should be fixed to the target tightly. Electric discharging or breakage might happen.
- * Do not apply impact such as dropping or vibration. If strong vibration or impact is applied, the cathode is damaged, which leads to deterioration of UV output stability and reduced lifespan, and may lead to damage to the built-in light source lamp.
- * In case of damage, it may cause injury due to fragments, etc. Please dispose of it with care.
- * Do not use in places where dangerous substances such as igniting or flammable materials exist. This product is not an explosion-proof product.
- * This product emits ultraviolet rays that are harmful to the eyes and skin. If you look directly at the light source or come into contact with the skin during grooming, it may cause inflammation. Wear shielding protection while handling.
- * It may affect the object to be irradiated such as plastic, such as yellowing and deterioration. Before use, check for any problems before use.
- * When turned on in the air, ozone is generated in the light source. Provide adequate ventilation.


⚠ CAUTION

- * Do not disconnect the output cable with power applied. There is a possibility of electric shock or malfunction.
- * Connect wires referring to the product manual. Wrong connection can cause failures.
- * For your proper cable connection, take a look at the manual 'Installation & Connection', for references. Any disordered connection is detected, the malfunction might arise.
- * All cables should be connected all the time. Please careful of cable disconnections. If power or communication cables got damaged, replace them immediately. Malfunction and fire danger may happen.
- * Do not install the device where the vibration can be detected. Any minor impact or vibration on the device, the malfunction or danger of accident might happen.
- * Do not use the item off the range of usage(Electrostatic elimination). Malfunction or danger of accident may occur.
- * Please install and use the warning label attached to the product so that it can be checked.
- * This product emits high-energy ultraviolet rays. Depending on the usage environment, a film that lowers the light transmittance of the radiation window may be formed by photochemical reaction (CVD), so lighting in a high vacuum or inert gas is recommended.
- * Do not touch the light irradiation window with bare hands. If the light is lit with fingerprint marks or dust on it, the light will be smudged and the radiation output intensity will be reduced.
- * Do not scratch the vacuum flange mounting part. There is a possibility that the vacuum flange performance will deteriorate and the vacuum may not be maintained.

2 Check the package contents


▶ Product compositions

The package includes the following products composition.



Head
SVH-K24
1~2ea

3 Nomenclatures of parts



4 Installation and connection

▶ Check the installation conditions head unit


Please check the installation condition whether it meets proper specification.

- Shielded room
- Be aware of any flammable or ignitable materials around the working area.
- There must be no objects between the target area and Ultraviolet ray device.
- Secure to have enough working space for quick maintenance of the device.
- No vibration on the fixed device.
- A place where there are few floating objects or foreign objects around


▶ How to connect

Connecting the VUV ionizer

Please connect the VUV ionizer and controller with supported "Head Cable".



5 Dimensions



6 Specification

▶ SVH-K24 (Head)

Parameter	Description / Value
Radiant Wavelength Range [Nm]	100nm to 200nm
Window Material	MgF2
Cooling Method	Air cooling by cooling fan
Guaranteed Service Life	1Year(warranty period) or 2,000Hr(warranty life time)
Weight	0.56Kg

※ The normal warranty period starts from the first date of your purchase. However, the expire date of warranty will be finished whichever reaches first either warranty period or used life time.

▶ Ambient temperature and humidity

Parameter	Description / Value	
Operation	Temperature	1°C to 40°C
	Humidity	20% to 90% RH
Storage	Temperature	-40°C to 70°C
	Humidity	90% RH

※ The appearance and specification of the product may be changed without prior notice for the improvement of the product.

SUNJE Electrostatics

www.sunstat.com

Head Office & Factory (Busan)

8 Cheongwang-gil, Ilgwang-Myeon,
Gijang-Gun, Busan, Korea
T) +82-51-720-7500 F) +82-51-720-7501

Sales Headquarter (Osan)

795 Naesammi-dong, Osan-si, Gyeonggi-do,
Korea
T) +82-31-203-9034 F) +82-31-202-9034

Customer Center +82-70-7714-9033
Sales Contact +82-31-203-9034

Sunje Japan Co., Ltd.

Dai 7 Matsuya Bldg 10F 1005 2-23, Honmachibashi,
Chuo-ku, Osaka, Japan
T) +81-6-6949-5001 F) +81-6-6949-5011

Sunje (SHANGHAI) Trading Co., Ltd.

Block C, 4F, No.482, Hongxu Road, Minhang District,
Shanghai, China
T) +86-21-5433-9761 F) +86-21-5433-9762

Sunje Technology Co., Ltd.

2F, No.6, Lane. 102, Sinhe Rd, Simfong Township,
Hsinchu County, Taiwan 30472
T) +886-3-568-7891 F) +886-3-568-7950